

# Concrete Repair

Fine to Med Concrete  
Cracks K125  
(Creamy Paste)

Medium to Larger  
Cracks K102  
(Mortar Paste)



To smooth surface ready for  
Painting, to fill blow holes  
Fairing Cream

## Notes Preparation

- Remove all loose debris and vacuum away all dust.
- Fine Cracks can be enlarged by way of saw chasing to aid filling
- Over fill and Sand Flush

For additional information visit

[www.nuplexconstruction.co.nz](http://www.nuplexconstruction.co.nz)

Ph - 0508 882288 Fx - 0508 553355

